



CROSS 1300 LADY

Rahmen / frame	Cross 7005 PG
Vorbau / stem	GHOST light AS-007N 31.8 mm
Gabel / fork	Suntour SF10-NEX LO 63 mm
Steuersatz / headset	Ritchey
Lenker / handlebar	GHOST Low Rizer light 660 mm 31.8 mm
Sattelstütze / seatpost	GHOST light SP 620 27.2 mm
Sattel / saddle	GHOST VL 3165
Schaltwerk / r. derailleur	Shimano Acera 8-Speed
Umwerfer / f. derailleur	Shimano
Schalthebel / shifter	Shimano Altus STI
Bremshebel / brake lever	Shimano Altus STI
Innenlager / bottom bracket	Shimano BBUN-26
Kurbelsatz / crankset	Shimano FCM 171 48-38-28
Bremsen / brakes	Shimano V-Brake
Vorderreifen / front tire	Schwalbe Smart Sam Sport
Hinterreifen / rear tire	Schwalbe Smart Sam Sport
Felgen / rims	Alex ACE 18
Speichen / spokes	DT Swiss 1.8
Naben / hubs	Shimano
Kassette / cassette sprocket	Shimano 11-30
Federelement / shock	-
Federweg vorne / front travel	63 mm
Federweg hinten / rear travel	-
Rahmenhöhen / frame sizes	40/44/48/52 cm
Farbe / colour	white / red / grey