



## MISS 8000

<b>Rahmen / frame</b>	Miss 7005 DB
<b>Vorbau / stem</b>	GHOST light AS-007N 31.8 mm
<b>Gabel / fork</b>	Rock Shox Recon Silver Air PopLoc 100 mm
<b>Steuersatz / headset</b>	Ritchey
<b>Lenker / handlebar</b>	GHOST Low Rizer light 640 mm 31.8 mm
<b>Sattelstütze / seatpost</b>	GHOST light SP 620 31.6 mm
<b>Sattel / saddle</b>	GHOST VL 4212 Lady
<b>Schaltwerk / r. derailleur</b>	Shimano XT 10-Speed
<b>Umwerfer / f. derailleur</b>	Shimano SLX
<b>Schalthebel / shifter</b>	Shimano SLX SL
<b>Bremshebel / brake lever</b>	Shimano 445
<b>Innenlager / bottom bracket</b>	Shimano BB51 BSA
<b>Kurbelsatz / crankset</b>	Shimano FCM 552 42-32-24
<b>Bremsen / brakes</b>	Shimano 445 Disc 180 mm
<b>Vorderreifen / front tire</b>	Schwalbe Smart Sam 2.1
<b>Hinterreifen / rear tire</b>	Schwalbe Smart Sam 2.1
<b>Felgen / rims</b>	Alex XD Sport
<b>Speichen / spokes</b>	DT Swiss 1.8
<b>Naben / hubs</b>	Shimano 435
<b>Kassette / cassette sprocket</b>	Shimano CS-HG62 11-34
<b>Federelement / shock</b>	-
<b>Federweg vorne / front travel</b>	100 mm
<b>Federweg hinten / rear travel</b>	-
<b>Rahmenhöhen / frame sizes</b>	34/40/44/48/52 cm
<b>Farbe / colour</b>	white / blue / silver